
Assembly Procedures






Automated Tin/Lead Dipping For SMP, SMPM & SMP3....

Our customized Automated Tin/ Lead Dipping Equipment enables high volume processing of our SMP, SMPM and SMP3 printed circuit board mount products. The finished connector is of high quality, with a consistent tin/lead flowed finish. Experience the Delta Difference!!!



 Trim cable to dimesions shown. Remove any burrs from outer and center conductor.



 Insert cable into body, making sure center conductor is inserted in slot in contact. Solder cable jacket to body, keeping end of cable flush with step in body as shown. Solder center conductor to contact and press cap into body until fully seated.

Proper assembly technique is important to the overall performance of the cable assemblies.